

Equipment Check

1. Turn Sensitivity Dial fully clockwise.

Note:

- clockwise rotation of sensitivity dial turns meter on and increases sensitivity.
- always set switch to highest sensitivity position, then decrease if necessary.

2. Depress the Battery Test button to test the battery and circuitry (excluding the probe when not in use).
3. Submerge the probe in tap water. This completes the circuit and activates the buzzer and light.

Routine Care

1. After the depth to water has been recorded, the cable should be carefully rewound onto the reel, the probe wiped dry and placed into the probe holder.
2. The probe, cable and reel can be cleaned with phosphate free (non-abrasive) detergent and warm water.
3. Use of a Water Level Meter Carrying Bag adds to the service life of the meter.
4. Use of the Tape Guide adds to the life of the cable.

Battery Replacement

- battery type - alkaline, 9 volt.

1. The battery is housed in a convenient battery drawer located in the faceplate of the Water Level Meter.
2. To replace the battery, simply press the drawer in, lift then pull.
3. The battery drawer should slide out of the faceplate enough to pull it out.

Note: The polarity and place another new battery in the drawer and slide it back into the faceplate.

Replacement Parts

The following parts can be provided should they become lost or damaged.

1. Probes
2. Reels
3. Replacement cable with probe (Complete)
4. Lights, switches, etc.
5. Splice kits

SYMPTOM	CAUSE	REMEDY
No sound when probe immersed in water.	Dead battery.	Replace with 9V Alkaline.
	Water conductivity is very low.	Increase sensitivity switch setting (turn clockwise) or call Solinst for assistance.
	Disconnected wires on circuit board.	Check all connections inside hub of reel for loose/disconnected wires - solder or reconnect.
	Broken wire in cable.	Locate break in cable - splice and seal. (Contact Solinst)
	Disconnected wire inside probe.	Contact Solinst to obtain parts/repair instructions.
Instrument continuously sounds after being immersed in water.	Water in probe. Probe may be dirty which could interfere with the circuit connection.	Contact Solinst for instructions to remove, clean and reseal.